

If there is a malfunction of any kind, contact your dealer for instructions on returning it for examination and repair.

(b) The TRANSFORMER or ADAPTOR cord is plugged into, and fully engaged in its receptacle.
(a) The TRANSFORMER or ADAPTOR is plugged into an electric outlet.

No user maintenance of this product is required. If the System does not function, be sure...

MAINTENANCE INSTRUCTIONS:

or physician's care, please contact them before using this product.

8. If you are subject to any medical condition involving the use of medical device products, and/or if you are under a health professional

7. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.

6. Keep the cord away from heated surfaces.

5. Do not use outdoors.

4. Close supervision is necessary when this appliance is used by, on, or near children or disabled persons.

3. Never operate the *Relaxor* product if it has a damaged cord or plug, or if it is not working properly. If it has been dropped or

2. Use this product only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.

or taking off parts.

1. Your *Relaxor* product should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on

WARNING! To reduce risk of burns, fire, electric shock, or injury to persons.

3. Do not use while bathing or in a shower.

2. Do not reach for a product that has fallen into water. Unplug immediately.

DANGER! To reduce risk of electric shock.

Read all instructions before using the Relaxor System.

IMPORTANT SAFETY INSTRUCTIONS



Relaxor[®]
Ultra
Massage System



OWNER'S MANUAL and OPERATING INSTRUCTIONS

Welcome to the world of Massage!

You are now the proud owner of another great *Relaxor* product.

Your new *Relaxor* massage system brings the comforting world of massage technology and places it at your fingertips. Now you can enjoy the relaxing feel of vibrating massage on your tired, knotted muscles by choosing from the dozens of pre-programed or self-programed settings.

We know you will enjoy your new *Relaxor* massage system product.

Limited Manufacturer's Warranty

Patents Pending

© Copyright 2007 InSeat Solutions, LLC. Santa Fe Springs, CA

RU85/RU85H

03/08

#111100U/#111100U-00

USE ONLY THE POWER SUPPLIED DEVICE WITH THIS PRODUCT
OPERATE YOUR SYSTEM ACCORDING TO THIS MANUAL

WARNING!

DANGER!

OPERATING INSTRUCTIONS

POWER

Activates Massage System

- Turn On: Press Power.
- Turn Off: Press Power again.

15 and 30 minute Timers:

Green light = 15 minute Timer.

Hold down Power:

Amber light = 30 minute Timer.

- Unit may also be turned on by pressing any ZONE 1-5 key.

To restart after Timer shuts off:

- Press Power or any ZONE 1-5 key.

HEAT

Activates Heat.

- Press LO (Amber light) to turn Low Heat on.
- Press HI (Red light) to turn High Heat on.

Works with massage or independently.

30 minute Timer

To continue after Timer shuts off, press LO or HI button again.

ZONES

(Green light indicates active Zone)

- 1 - Upper Back
- 2 - Lower Back
- 3 - Hip Region
- 4 - Thigh Region
- 5 - Calf Region

INTENSITY

Controls INTENSITY during all modes.

Press (+) to increase and (-) to decrease Intensity.

SPEED

Controls pulsing frequency of massage motors in PULSE mode and controls the velocity as it cycles through in WAVE, TAP and SWELL speeds.

Press (+) to increase and (-) to decrease speed.



MESSAGE MODES

(Green light indicates active Mode)

SELECT -

Lets you choose zones for steady massage.

- Press SELECT.
- Press any or all Zones (1- 5) to activate.
- Press any or all Zones (1- 5) to cancel.

WAVE -

Massage moves up and down in a wave-like action.

- Press WAVE.
- Press any or all Zones (1- 5) to activate.
- Press any or all Zones (1- 5) to cancel.

PULSE -

Massage turns On and Off to provide a pulsing action.

- Press PULSE.
- Press any or all Zones (1- 5) to activate.
- Press any or all Zones (1- 5) to cancel.

TAP -

Massage rapidly turns On and Off at high Intensity to provide a tapping action.

- Press TAP.
- Press any or all Zones (1- 5) to activate.
- Press any or all Zones (1- 5) to cancel.

SWELL -

Massage cycle from minimum to maximum intensity to provide a swelling action.

- Press SWELL.
- Press any or all Zones (1- 5) to activate.
- Press any or all Zones (1- 5) to cancel.

SAVE THESE INSTRUCTIONS!