

1-562-447-1780

or give us a call at:

11839 Smith Avenue, Santa Fe Springs, CA 90670  
Write to: Customer Service InSeat Solutions, Inc. Corporate Office  
If you need assistance for any reason, please contact us:

If there is a malfunction of any kind, contact your dealer for instructions on returning it for examination and repair.

- (a) The TRANSFORMER or ADAPTOR is plugged into an electric outlet.
- (b) The TRANSFORMER or ADAPTOR cord is plugged into, and fully engaged in its receptacle.

No user maintenance of this product is required. If the System does not function, be sure....

### MAINTENANCE INSTRUCTIONS:

or physician's care, please contact them before using this product.

- 8. If you are subject to any medical condition involving the use of medical device products, and/or if you are under a health professional
- 7. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- 6. Keep the cord away from heated surfaces.
- 5. Do not use outdoors.
- 4. Close supervision is necessary when this appliance is used by, on, or near children or disabled persons.
- 3. Never operate the *Berkline*® product if it has a damaged cord or plug, or if it is not working properly. If it has been dropped or damaged, or dropped into water, contact your dealer for instructions on returning it for examination and repair.
- 2. Use this product only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer, or taking off parts.
- 1. Your *Berkline*® product should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on

### WARNING! To reduce risk of burns, fire, electric shock, or injury to persons.

- 1. Always unplug the product from the electrical outlet immediately after using and before cleaning.
- 2. Do not reach for a product that has fallen into water. Unplug immediately.
- 3. Do not use while bathing or in a shower.

### DANGER! To reduce risk of electric shock.

Read all instructions before using the *Berkline*® System.

# IMPORTANT SAFETY INSTRUCTIONS



**BERKLINE**®

ROHO® Shape Fitting Technology®

### OWNER S MANUAL and OPERATING INSTRUCTIONS

You are now the proud owner of another great *Berkline*® Recliner.

Your new *Berkline*® Air System delivers the comfort of ROHO® Shape Fitting Technology® and places it at your fingertips. Now you can adjust your comfort to your individual settings. If you like a setting, you can use our new programming buttons to give you comfort in just one touch.

We know you will enjoy your new *Berkline*® Recliner.

Limited Manufacturer s Warranty

Patents Pending

ROHO® Shape Fitting Technology® is a Patented Product and Registered Trademark by the ROHO Group, Inc.

Copyright 2007 InSeat Solutions, LLC. Santa Fe Springs, CA

USE ONLY THE POWER SUPPLIED DEVICE WITH THIS PRODUCT  
OPERATE YOUR SYSTEM ACCORDING TO THIS MANUAL

### WARNING!

### DANGER!

# OPERATING INSTRUCTIONS

## INSTALLATION NOTE:

Constant wand lights indicate that there is active power in the wand and will dim after 20 seconds of non-use.

## MEMORY BUTTONS

Either button (P1 or P2) allows system customization.

- How To Program:
  - Press SELECT and choose the comfort number for the BACK. Repeat for SEAT.
  - Once the comfort numbers are selected, press and hold P1 (LED light will start flashing).
  - Release P1 and the numbers are now in memory. Press P1 to activate program at any time.

Repeat for P2 (Choose different numbers, recommended).

## PRESSURE DISPLAY

(Brighter LED indicates active Zone)

B - BACK

S - SEAT

LED dims after 20 seconds of non-use.



## ADJUSTMENT BUTTONS

- Press the SELECT button to activate one of the 2 adjustment zones; B(Back) or S(Seat). LED will be brighter on active zone.
- Press the + button to increase firmness or the - button to decrease firmness. Numbered LED s for BACK and SEAT will adjust in increments of 5. (00 being the lowest setting and 99 being the maximum)
- LED will start flashing to indicate the system is working to reach desired comfort number.
- WAIT. LED will stop flashing when adjustment is complete. This can take several seconds.

Repeat these steps as needed.

## SYSTEM NOTE:

- Maximum body weight should be no more than 280 lbs.
- Dynamic Comfort Numbers will differ due to individual body weight...50 for one person could read 70 for another.

**SAVE THESE INSTRUCTIONS!**